


ZoomLink Transmitter

Button to adjust lavalier length


Lavalier with integrated antenna

Microphone buttons

Microphone Openings (worn 8-10 inches from speaker's mouth)




Wear front side facing out




LCD

CLIP

Pen push for channel change



External connection interface







(battery charger)

Front

Back

On/Off:
Long press (2 seconds) on desired **microphone setting**

Microphone Settings

<p>Super Zoom (narrow-angle) Worn by speaker</p>		
<p>Zoom (wider-angle) Directed toward the speaker</p>		
<p>Omni (360 °) Place on table when working in a group</p>	